

BEDIENUNGSANLEITUNG

KLIMAANLAGE Dreh das Thermostat am unteren Ende des Gerätes auf **K**. Drücke die Taste „**Mode**“ bis es **blau** blinkt. Wenn es **pink** blinkt, befindest Du Dich im Umluftbetrieb. Mit + und - regulierst Du die Intensität.

HEIZUNG Drück die Taste „**Mode**“ bis es **rot** blinkt. Drehe zusätzlich das Thermostat am unteren Ende auf **Stufe 1-5**. Nachdem das Blinken aufgehört hat, startet nach wenigen Minuten der gewünschte Betrieb. Mit + und - regulierst Du zusätzlich die Intensität vom Gebläse.

OPERATING INSTRUCTION

AIRCONDITION Turn the circulator on the bottom of the radiator to **K**. Then push the button „**mode**“ on the top until it is flashing **blue**. If it is flashing **pink** you have an air circulation. With + and - you adjust the intensity.

HEATING Push the button „**mode**“ until it is flashing **red**. Additionally you need to turn the circulator on the bottom of the radiator to **level 1-5**. After the flashing lights stopped the chosen service starts after a couple of minutes. You can change the intensity of the blower with + and -.

» TOO HOT OR COOL DOWN?

